



SPAN® Data Logging for Inertial Explorer®

Overview

This document provides an overview of the OEM6 and OEM7 SPAN® logs used for post-processing in Inertial Explorer® (IE) 8.70. A list of required logs outlines the minimum logging requirements needed for post-processing. Additional logs are recommended for increased ease of use, specific applications, and troubleshooting purposes. Example lists of commands and logs are provided at the end of the document, which can be used as templates for basic data collections.

Data Logging

Log Types & Headers

There are multiple logging formats which can be used to record NovAtel receiver data. Table 1 provides a summary of these formats and select examples. It is recommended to log data records in binary format, as the NovAtel/OEM decoder in IE supports only binary logs. After data conversion, all decoded logs will be displayed in the conversion summary. Further details on data types and log formats can be found in the OEM User Manuals.

Table 1: Logging Different Formatting Types

	Log Type	Symbol	Example Log
Data Type	ASCII	-	INSPVA
	Binary	B	INSPVAB
Log Format	Short Header	S	INSPVAS
	Extended	X	INSPVAX
	Compressed	CMP	RANGECMP
Example: RAWIMUSXB Extended version [X] of a Binary Log [B] with a Short header [S]			

Logging Triggers & Frequency

The choice of logging triggers depends on the log itself, and how the data is used in post-processing. Each log trigger outputs the current message immediately after it has been called.

ONCE: Outputs the current message only once.

ONCHANGED: The log is output only when the values in the message change.

ONNEW: The log will be output every time the log is updated. This ensures that internally triggered logs are also output.

ONTIME <#>: The log will continually be requested and output every <#> seconds during data collection.

The choice between ONNEW and ONCHANGED is dependent on the type of data collection and user preferences. The ONNEW trigger can result in larger files with duplicate logs that are ignored by IE's converter. The ONCHANGED trigger is preferable to avoid duplicates and minimize file size. However, if the ONCHANGED log request is made before the logging file is opened the log will not be triggered until a



value has changed. This may cause issues in short surveys, as slow changing logs (such as RAWEPHEMB) may not be logged during the data collection period. For this reason, ONNEW is suggested for short surveys.

If using ONCE, the user must ensure that the logging file has been opened before the log call. If not, the information will not be saved anywhere in the file, as the log will not be called again.

While in INS operation, the highest rate that GNSS logs should be requested is 5 Hz (0.2 seconds). GNSS logs include, but are not limited to, RANGECMPB, BESTPOSB, BESTGNSSPOSB, RTKPOSB and PSRPOSB.

The recommended rate for all GNSS logs is 1 Hz for GNSS and INS Integration.

SPAN Logs

The following list outlines the logs required and recommended for post processing in IE. For differential processing, a subset of these logs must be logged at the base. The *'Required for'* note describes how IE uses the data provided in the log. Suitable *'Alternative'* logs are also listed, which can be selected based on user preference. The *'Used for'* note describes how IE uses the data provided in the log. Not all logs will be used in IE post-processing, but can be *'Helpful for'* troubleshooting purposes and record keeping. Finally, *'Requirement'* notes outline prerequisite steps needed for the successful output of the log.

Platform Compatibility: OEM6 & OEM7 **OEM6 ONLY** **OEM7 ONLY**
Log on Receiver Type: R: ROVER M: MASTER

Required Logs

These logs are required to collect the raw data necessary for post-processing.

LOG RANGECMPB ONTIME 1	R M	Satellite range information. Channel measurements for the currently tracked satellites. Required for: GPB file creation and GNSS data processing; source of GNSS raw data. Alternatives: RANGEB, RANGECMP2B
LOG RAWEPHEMB ONNEW	R M	GPS raw ephemeris information. Required for: Computing GPS satellite coordinates and elevation.
LOG GLOEPHEMERISB ONNEW	R M	GLONASS raw ephemeris information. Required for: Computing GLONASS satellite coordinates and elevation. Alternatives: GLORAWEPHEMERISB



LOG RAWIMUSXB ONNEW

R

Raw gyroscope and accelerometer measurements, including an IMU status indicator.

Required for: IMR file creation and INS data processing; provides sequential changes in velocity and rotation.

Directions: Must log ONNEW. Use the extended header to include the name of the IMU. This helps to ensure correct conversion in Waypoint products.

Alternatives: RAWIMUB, RAWIMUSB, RAWIMUXB

Recommended Logs

The following logs are not required for post-processing, but provide information that aids in project setup, data analysis, and troubleshooting. A number of logs specified below are used for extracting real-time trajectories to a Waypoint readable format. Instructions on how to generate these files are provided in *Appendix A: Full Project Example*.

LOG VERSIONB ONCE	R M	Version information for all system components. Used for: Keeping record of the system components of the data collection.
LOG RXCONFIGB ONCE	R M	Receiver configuration. List of all current command settings. Helpful for: Support and troubleshooting. Note: Log after the configuration commands are sent.
LOG RXSTATUSB ONCE	R M	Receiver Status. List of GNSS receiver system status (health) parameters. Helpful for: Support and troubleshooting; Can identify error conditions affecting performance.
LOG THISANTENNATYPEB ONCE	R M	The antenna type of the receiver in use. Used for: Setting the antenna profile. Requirement: User must first set the antenna profile through the THISANTENNATYPE command.
LOG INSPVAXB ONTIME 1	R	INS position, velocity and attitude in the SPAN computation frame and their estimated errors. Used for: Extracting real-time trajectory to a Waypoint readable format. Note: If high rate INSPVA logs are needed, but bandwidth is a concern, use INSPVASB and INSCOVSB as alternatives.
LOG BESTPOSB ONTIME 1	R	Best available combined GNSS and INS solution output at the GNSS phase center. Used for: Extracting real-time trajectory to a Waypoint readable format, and decoding position estimated by the receiver to the GPB file.
LOG BESTGNSSPOSB ONTIME 1	R	Best available GNSS solution computed without INS. Used for: Extracting real-time trajectory to a Waypoint readable format.
LOG TIMEB ONTIME 1	R M	Time related information such as receiver clock offset, and UTC time and offset. Used for: Decoding receiver clock shift to GPB file.



**LOG SETIMUORIENTATIONB
ONCHANGED**

R

Orientation of the IMU frame in the SPAN computation frame. Specifies the IMU axis aligned with gravity.
Used for: IMU alignment settings.
Requirement: User must first set values through the SETIMUORIENTATION command.

**LOG IMUTOANTOFFSETSB
ONCHANGED**

R

Lever arm offset from the IMU to the GNSS antenna.
Used for: IMU alignment settings.
Requirement: User must first set values through the IMUTOANTOFFSETS command.

**LOG VEHICLEBODYROTATIONB
ONCHANGED**

R

Rotation from the Vehicle frame to the SPAN frame.
Used for: IMU alignment settings.
Requirement: User must first set values through the VEHICLEBODYROTATION command.

LOG INSCONFIGB ONCHANGED

R

All IMU configuration parameters required for post-processing or system analysis.
Used for: IMU alignment settings.
Requirement: User must first set values using variations of the SETINSTRANSFORMATION and SETINSROTATION commands. For the commands specific to your system setup, see SPAN documentation.

Supplementary Logs: Common Applications

This section outlines the logs required for integration of application-specific data in Inertial Explorer. Please note that this list contains only the logs required in IE, and does not encompass all logs and commands required for the proper set up and real time tracking of these systems. Further information on application-specific setup can be found in the OEM User Manuals.

Constellations

The following Ephemeris logs can be decoded in IE. RAWEPHEMB and GLOEPHEMERISB are considered as Required Logs, but are listed here for completion.

LOG RAWEPHEMB ONNEW	R M	GPS ephemeris information
LOG GLOEPHEMERISB ONNEW	R M	GLONASS ephemeris information
LOG BDSEPHemerisB ONNEW	R M	BeiDou ephemeris information
LOG GALEPHEMERISB ONNEW	R M	Galileo ephemeris information *
LOG QZSSEPHemerisB ONNEW	R M	QZSS ephemeris parameters

* The log GALEPHEMERIS is being deprecated and will eventually be replaced by GALINVAEPHEMERIS and GALFNAVEPHEMERIS. As these two new logs are not yet supported by IE, the continued use of GALEPHEMERIS is recommended.

Dual Antenna (ALIGN Solution)

LOG HEADINGB ONNEW	R	Angle from true north of the base ALIGN antenna to the rover ALIGN antenna (positive clockwise direction). Used for: HMR file creation. Requirement: User must first set the two lever arm values using SETIMUTOANTOFFSET, SETIMUTOANTOFFSET2.
LOG HEADING2B ONNEW	R	Angle from true north of the base ALIGN antenna to the rover ALIGN antenna (positive clockwise direction). Used for: HMR file creation. Requirement: User must first set the two lever arm values using SETINSTRANSALATION ANT1, SETINSTRANSALATION ANT2.

Wheel Sensor (Distance Measurement Instrument - DMI)

LOG TIMEDWHEELDATAB ONNEW	R	Time stamped wheel sensor data. Used for: Ticks per revolution in the DMR file.
LOG SETWHEELPARAMETERSB ONCHANGED	R	Wheel sensor parameters Used for: Sensor parameters in the DMR file header. Requirement: User must first set the number of ticks per revolution, wheel circumference, and the resolution of the wheel sensor in the SETWHEELPARAMETERS command. Note: These DMI parameters can also be set in the <i>Global Options</i> window of the <i>Convert Raw GNSS data to GPB</i> utility.

Miscellaneous

LOG MARKTIMEB ONNEW	R	Time of mark input event. Used for: Measure the time when events are occurring in other devices. Note: Other mark input event logs include MARK2TIMEB, MARK3TIMEB, and MARK4TIMEB.
----------------------------	----------	--

Appendix A: Full Project Example

This section provides an example of how a well-planned list of logs and commands will allow for an efficient work flow in Inertial Explorer. The following SPAN data collection uses GPS and GLONASS constellations, a dual antenna system, and set up with the default IMU orientation (standard Y forward, Z up, X right). The equivalent OEM6 and OEM7 logs and commands used in this data collection are listed below to provide a summary example. The figures on the following pages demonstrate how the information from these logs is used in IE to convert and generate files, and auto-fill set up parameters for the project.

Logs and Commands

OEM6

```
CONNECTIMU COM2 IMU_ADIS16488
SETIMUTOANTOFFSET -0.976 -1.661 1.551
0.03 0.03 0.03
SETIMUTOANTOFFSET2 -1.021 0.890 1.567
0.03 0.03 0.03
VEHICLEBODYROTATION 0 0 0
SETIMUORIENTATION 5
THISANTENNATYPE NOV702

LOG VERSIONB ONCE
LOG RXCONFIGB ONCE
LOG RXSTATUS ONCE
LOG THISANTENNATYPEB ONCE

LOG HEADINGB ONNEW
LOG VEHICLEBODYROTATIONB ONCHANGED
LOG SETIMUORIENTATIONB ONCHANGED
LOG IMUTOANTOFFSETSB ONCHANGED

LOG RANGECPMB ONTIME 1
LOG RAWEPHEMB ONNEW
LOG GLOEPHEMERISB ONNEW
LOG RAWIMUSXB ONNEW

LOG TIMEB ONTIME 1
LOG BESTPOSB ONTIME 1
LOG BESTGNSSPOSB ONTIME 1
LOG INSPVAXB ONTIME 1
LOG INSUPDATEB ONCHANGED
```

OEM7

```
CONNECTIMU COM2 IMU_ADIS16488
SETINSTRANSLATION ANT1 -0.976 -1.661 1.55
0.03 0.03 0.03
SETINSTRANSLATION ANT2 -1.021 0.890
1.567 0.03 0.03 0.03
SETINSROTATION RBV 0 0 0
THISANTENNATYPE NOV702

LOG VERSIONB ONCE
LOG RXCONFIGB ONCE
LOG RXSTATUS ONCE
LOG THISANTENNATYPEB ONCE

LOG HEADING2B ONNEW
LOG INSCONFIGB ONCHANGED

LOG RANGECPMB ONTIME 1
LOG RAWEPHEMB ONNEW
LOG GLOEPHEMERISB ONNEW
LOG RAWIMUSXB ONNEW

LOG TIMEB ONTIME 1
LOG BESTPOSB ONTIME 1
LOG BESTGNSSPOSB ONTIME 1
LOG INSPVAXB ONTIME 1
LOG INSUPDATEB ONCHANGED
```

Data Conversion

Data conversion can be done with *Convert Raw GNSS data to GPB* Utility. Use the “Get Folder” button to browse to the folder containing the raw GNSS data, and then use the “Auto Add All” feature to add all raw GNSS data, including NovAtel data, for conversion.

A number of logs, specified in the Recommended Logs list, are used to generate real time trajectory files




Figure 1: GNSS Raw Data Converter Utility – Auto-detect the NovAtel OEM7 / SPAN Receiver Type during data conversion. After the raw data file is added, click either the *Global Options* or *Options* button, and check off *Create trajectory files for supported records*. After the data has been converted, the trajectory files can be loaded and viewed in IE, to compare against the post-processed solutions.




Figure 2: GNSS Raw Data Converter Utility - Generate real time trajectory files during data conversion

Data Files

Depending on the type of data logged, a number of file types will be generated and saved in the same directory as the original raw data file. As shown in Figure 3, the data used in this example generated the *.epp, *.gpb, *.hmr, *.imr, *.sta and real time trajectory files (*.fp and *.ft). Table 2 lists all of the files which can be produced upon data conversion; not all data sets will contain the relevant data to produce all of these files. When the GPB file is loaded into the project as a Rover or Master, the other file types are also added.




Figure 3: Files generated after raw data conversion of this example data set.

Table 2: All possible file types generated from data conversion

File Type	Type of Data
DMR	DMI data
EPP	GNSS ephemeris records
FP, FT	Real-time trajectory files
GPB	Raw GNSS data
HMR	Heading data
IMR	IMU data
MMR	Mount data
STA	Camera marks, antenna profile, station names

Auto-Fill Set Up Parameters

With this data logged, converted, and added to the project, users can then auto-fill a variety of parameters in the Processing Settings. Figure 4, Figure 5, and Figure 6 show the parameters filled using the logs recorded in the example data collection.




Figure 4: When adding a remote or base station file, the Antenna Profile will be auto-filled using information from the THISANTENNAYPEB log, read in from the STA file.




Figure 5: The Lever Arm and IMU rotation will be auto-filled from the IMR file.




Figure 6: Heading parameters are auto-filled from the HMR file. The Gimbal Mount and Distance Measuring Instrument values are auto-filled when MMR and DMI files, respectively, are added to the project.

Additional Information

OEM User Manuals

Further details on the logs and commands outlined in this document can be found in the NovAtel OEM User Manuals.

OEM6:

SPAN on OEM6 Firmware Reference Manual:

<https://www.novatel.com/assets/Documents/Manuals/OM-20000144UM.pdf>

OEM6 Family Firmware Reference Manual:

<https://www.novatel.com/assets/Documents/Manuals/om-20000129.pdf>

OEM7:

Documentation Portal:

<http://docs.novatel.com/OEM7/Content/Home.htm>

Waypoint Product Manuals:

Detailed instructions on using Inertial Explorer 8.70 can be found in the Waypoint User Manuals:

GNSS Features:

GrafNav / GrafNet / GrafNav Static User Manual:

<https://www.novatel.com/assets/Documents/Waypoint/Downloads/GrafNav-GrafNet-User-Manual-870.pdf>

IMU Features:

Inertial Explorer User Manual:

<https://www.novatel.com/assets/Documents/Waypoint/Downloads/Inertial-Explorer-User-Manual-870.pdf>

Support:

To search for more information or submit a support case, please visit NovAtel's support page:

<http://www.novatel.com/support/>